



After attaching formers,
glue to bottom of profile.
Match location with hole in fuselage

Battery hatch

