



Align back of Upper Front Deck Here	Upper deck flush with Nacelle	SPAR GOES HERE. Remove after assembly

