



1/8" Plywood



9mm OD - 3M Blind Nuts

1/8" Plywood



9mm OD - 3M Blind Nuts

Remove after wing mounting

1/8" Plywood  
Outside

Epoxy 4mm wood  
screw block

1/8" Plywood  
Inside

Epoxy 4mm wood  
screw block