

The Landing Gear must bottom
out against the Plywood spars.
Remove the paper and foam.

