




HORIZONTAL STABILIZER




FRONT SKIN 3 TOP




F6




VERTICAL STABILIZER









FRONT SKIN 1




FRONT SKIN 2 BOTTOM





FRONT SKIN 2 TOP





-  Reference
-  100% Cut
-  50% Cut
-  45 Degree Edge Bevel
-  Remove Foam



REAR CENTERPOD





53



F3 BOTTOM

F3 BOTTOM








F2




F2




F3 TOP






RIGHT WING







RIGHT SPAR












F4




F1









LEFT SPAR






LEFT \



WING








STABILIZER


FRONT

SKIN 3 TOP




SKIN 2 BOTTOM

HORIZONTAL :



F6

VERTICAL STABILIZER






FRONT

SKIN 1

FRONT

SKIN 2 TOP






SKIN 4


Faux Cowling

FROM




SKIN 5 BOTTOM


FRONT




SKIN 5 TOP

FRONT





CANOPY



Reference

100% Cut

50% Cut

45 Degree Edge Bevel

Remove Foam